

HEATING AND HOT WATER

WIRING DIAGRAM FOR LAYOUT 3 USING THE HORSTMANN H27XL SERIES 2

ANTI-CYCLING CONTROL. WIRING LAYOUT

Gas or oil fired boiler only.
 Hot water only. A on B off
 Heating and hot water. A on B on

Solid fuel boiler only.
 Heating and hot water. A off B on
 Hot water only or slumber. A off B off

Solid fuel boiler with Gas or oil fired boiler.
 Heating and hot water. A on B on

Anti-boil control.
 In the event of an overheat situation developing. Anti-boil stat (2) set at 85°C Will make and switch on the space heating pump.

